



## DL-S41-H2 Firmware Upgrade V1.0.1

How long will this take?

2-3 minutes per device

What will you need?

(1) PC With Windows 10 OS


(1) Micro USB to USB A cable.

What does this update do?


Stabilizes 1080p video when using HDMI extension devices with the DL-S41-H2

Instructions:

1. Unzip the firmware zip file labeled **DL-S41-H2\_V1.0.1 FIRMWARE\_UPDATE.zip**
2. Disconnect the power cable of the DL-S41-H2.
3. Connect the Firmware USB port of the DL-S41-H2 receiver to a PC using a Micro USB to USB A cable, the PC will apply USB bus power to the DL-S41-H2 for the update.
4. When the USB cable is connected and the DL-S41-H2 is powered, a USB drive will appear in your PC automatically, you will see a file named READY



5. Drag and drop the firmware file labeled **DL-S41-H2 V1.0.1** (.bin file) to this disk, the firmware update will automatically process. The disk will refresh and the file name will be changed to "Success", this means the firmware is updated successfully. If this fails, please check the file and the connection to the device from the PC, then repeat this step again.



6. Disconnect the USB Micro cable from the DL-S41-H2 and reconnect the DL-S41-H2 power supply.

The update is complete