

GENERAL INFORMATION

SIMPL WINDOWS NAME	Intelix ASW-WP demo.smw
CATEGORY	Video switching
VERSION	1.0.0.1
SUMMARY	Controls the Intelix ASW-WP via RS-232
GENERAL NOTES	Controls switching of sources to output. Provides HDCP compliance control. Provides explicit polling command. Provides true feedback.
CRESTRON HARDWARE REQUIRED	2- or 3-SERIES PROCESSORS
COMMUNICATION SETUP	RS232: 9600 Baud, No Parity, 8 Data Bits, 1 Stop Bit
VENDOR FIRMWARE	Pro2: 4.007.0004 MC3: 1.008.0040

CONTROL

rx	S	Connect to serial receive input
Initialize	D	Pulse to enable device control
Source_HDMI	D	Pulse to choose HDMI as selected input
Source_PC_VGA	D	Pulse to choose PC VGA as selected input
Auto_Switch_On	D	Pulse to enable auto switch (displays last connected source)
Auto_Switch_Off	D	Pulse to disable auto switch
HDCP_Enable	D	Pulse to enable HDCP compliance
HDCP_Disable	D	Pulse to disable HDCP compliance
Poll	D	Pulse to poll unit for current state
Standby	D	Pulse to engage standby mode
Reset	D	Pulse to restore factory default settings

FEEDBACK

tx	S	Connect to serial transmit output
Source_HDMI_fb	D	True feedback; reports selected source is HDMI
Source_PCA_VGA_fb	D	True feedback; reports selected source is PC VGA
HDMI_Present	D	True feedback; reports HDMI input is connected
PC_VGA_Present	D	True feedback; reports PC VGA input is connected
Auto_Switch_On_fb	D	True feedback; reports auto switching is enabled
Auto_Switch_Off_fb	D	True feedback; reports auto switching is disabled
HDCP_Enable_fb	D	True feedback; reports HDCP is enabled
HDCP_Disable_fb	D	True feedback; reports HDCP is disabled
Poll_Busy_fb	D	Reports poll command is executing