Specifications

Specifications subject to change without notice.

| Maximum Distance* | 1000 feet |
|--|---|
| Maximum Input | 1.1 Vp-p |
| Bandwidth (video) | DC to 6 MHz |
| Bandwidth (audio) | 20 Hz to 20 kHz |
| Impedance (video) | 75 ohms |
| Impedance (audio) | 600 ohms minumum |
| Insertion Loss | Less than 2 dB per pair over the frequency range |
| Return Loss | Greater than 15 dB over the frequency range |
| Common Mode Rejection | Greater than 40 dB over the frequency range |
| Unshielded Twisted Pair Cabling Specifications (24 gauge or lower solid copper) | Maximum capacitance: 20 pf/foot Impedance: 100 ohms @ 1 MHz Attenuation: 6.6 dB/1000 ft. @ 1 MHz <i>Cat 5, Cat 5e, Cat 6, Cat 7 compatible</i> |
| Connectors | One (1) S-Video 4-pin and two (2) RCA to one (1) RJ45 |
| RJ45 Pinout | S-Video Luma: 7 & 8, pair 4 S-Video Chroma: 4 & 5, pair 1 Audio 1: 1 & 2, pair 2 Audio 2: 3 & 6, pair 3 |
| Temperature | Operating: 32 to 131 F (0 to 55 C) Storage: -4 to 185 F (-20 to 85 C) Humidity: up to 95% |
| Enclosure | Black plastic |
| Dimensions | 4.3" x 2.5" x 1" |
| Weight | 0.2 lbs (3.2 oz.) |
| Ordering Information | AVO-SVA2-F: single AVO-SVA2-F balun in bulk packaging AVO-SVA2-PAC-F: two AVO-SVA2-F baluns in retail-ready packaging |
| Warranty | 2 years |

* Distances and picture quality may be affected by cable grade, cable quality, source and destination equipment, RF and electrical interference, and cable patches. Intelix specifications are based on straight-through cabling with standard-grade Cat 5.

Contact Information



AvoC

Intelix 2222 Pleasant View Road Middleton, WI 53562

Toll-free: 866-4-MATMIX Phone: 608-831-0880 Fax: 608-831-1833 www.intelix.com



AvoCat Series Installation Manual



The AVO-SVA2-F balun allows the transmission of a single S-Video signal and two analog audio signals over unshielded twisted pair (UTP) cable, such as Cat 5. Used in pairs, AVO-SVA2-F baluns eliminate costly and bulky S-Video cable, allowing the connection of S-Video equipment to any convenient modular outlet.

The AVO-SVA2-F balun allows pre-existing twisted pair cable to be used in such applications as classroom video distribution,

overhead projector systems, PC-training systems, and tradeshow PC-demo systems in the S-Video environment.

Installation

Caution: Do not attempt to open the balun housing. There are no user-serviceable parts inside the AVO-SVA2-F. Opening the unit will void your warranty.

To install an AVO-SVA2-F balun, perform the following steps:

- 1. Turn off power and disconnect the S-Video source and S-Video monitor.
- 2. Make certain the modular outlets and cross connects to which you will connect the AVO-SVA2-Fs are configured properly and labeled appropriately to identify the circuit.

Caution: Do not connect the AVO-SVA2-F to a telecommunication outlet wired to unrelated equipment. Making such a connection may damage the equipment and/or balun. Please ensure all wiring is "straight-through."

3. Verify the desired twisted pairs are not used with other LAN or telephone equipment.

4. Connect the balun to the S-Video port of the source equipment (i.e., DVD or VCR). Connect the audio connectors to the audio source.

Caution: Do not mount the balun over equipment ventilation openings. Covering the openings may cause the equipment to overheat.

- 5. Connect a 4-pair Cat 5 cable from the RJ45 8-position modular jack of the AVO-SVA2-F to a structured cable, such as Cat 5.
- 6. Connect the second balun's RCA inputs to the destination equipment.
- 7. Connect the 4-pair Cat 5 cable from the RJ45 8-position modular jack of another AVO-SVA2-F to the structured cable attached to the first balun.
- 8. Power on the S-Video equipment at both ends and adjust the monitor image and audio levels to the desired settings.

Troubleshooting

If your equipment malfunctions with AVO-SVA2-F baluns in place, follow the trouble-shooting procedures below:


- 1. Perform diagnostics on your audio equipment by following the manufacturer's instructions.
- 2. Check all the connections and the structured cabling system. Verify the RJ45 crimp pattern conforms to either EIA/TIA 568A or 568B standards.
- 3. Check the pin configuration of the structured cabling.
- 4. The maximum operational distances over which the AVO-SVA2-F can be transmitted is dependant on the equipment used and cable. Ensure that the maximum recommended operational distances have not been exceeded.
- 5. Check that only twisted pair patch cords are being used.
- 6. Replace the AVO-SVA2-F balun with another AVO-SVA2-F that is known to be working.
- 7. If you still cannot diagnose the problem, contact Intelix for support.

Frequently Asked Questions

How do I expose the individual pairs in Cat 5 cabling?

There is no single method when exposing the four individual pairs in twisted pair cabling, such as Cat 5 and Cat 6; however, it does help to have a cable stripping tool designed to strip the cable jacket/insulation.

Begin by stripping back the cable's outer jacket/insulation about an inch (or more depending on whether multiple baluns will be connected to the pairs of a single cable) so that the internal wires are exposed. Be careful not to cut the internal wires when stripping the insulation/jacket. Eight twisted wires and a string should now be visible; the string is unnecessary and may be removed. These eight wires, which when combined form four pairs, connect directly to the baluns. Typical protocol pairs similar colors; the important thing is to verify the same color-coded pairs are used on each end.




How do I crimp an unshielded RJ45 connector onto Cat 5?

Crimping an RJ45 connector onto Cat 5 is a fairly straight forward task, assuming you have the proper tools. Keep in mind that baluns require either the EIA/TIA 568A or 568B crimp pattern, which are the industry standards for networking.

- 1. First, strip a portion of the insulation about 3/4" to expose the four twisted pairs.
- 2. Next, untwist the wires and fan them out so that they match either EIA/TIA 568A or 568B pattern.
- 3. Evenly trim the wires to about 1/2". Most RJ45 crimp tools feature a built-in wire trimmer.
- 4. Insert the trimmed wires into the RJ45 connector so that each wire is in its individual slot. Verify each wire is completely inserted.
- 5. Finally, insert the RJ45 connector into the crimp tool and squeeze firmly.
- 6. Repeat the above steps on the other end of the Cat 5 cable and verify pinout is identical on each end.

EIA/TIA 568A Crimp Pattern Standard



EIA/TIA 568B Crimp Pattern Standard

